

Cleaning and Disinfection instructions

GRIPHEN®

March 2020

Cleaning and disinfection instructions for GRIPHEN®:

Clear copolyester (PETG) sheet extruded by Arla Plast, and parts therefrom.

- GRIPHEN may be cleaned by using a clean soft sponge and washing with lukewarm water containing a mild soap or a slightly acidic, neutral or slightly alkaline detergent. Then rinse thoroughly with clean water and dry with a chamois leather or a moist sponge. A subsequent anti-static treatment is recommended.
- Disinfection of the GRIPHEN surface can be performed using > 60% isopropyl alcohol (IPA), ethanol, or any other antibacterial or antiviral cleaning agent suitable for PETG sprayed or applied on a soft cloth. If necessary, followed by a wash with clean water and rinse as described above.
- Treatment with an anti-static agent keeps the sheet free from static charge and dust over prolonged periods. There are commercially available products which act simultaneously as cleaning agent and anti-static agent, e.g. Burnus Kunststoff-Reiniger + Pfleger.

For more information contact infocz@arlaplast.com or check our website www.arlaplast.com

Arla Plast sro management system is certified according to ISO 9001:2015, ISO 14001:2015 and OHSAS 18001: 2007, and energy management system to ISO 50001:2011.