

Cleaning and Disinfection instructions

MAKROCLEAR, COLORADO

March 2020

Cleaning and disinfection instructions for MAKROCLEAR™ and COLORADO®:
Clear or coloured polycarbonate (PC) sheet extruded by Arla Plast, and parts therefrom.

- MAKROCLEAR/ COLORADO sheet may be cleaned by using a clean soft sponge and washing with lukewarm water containing a mild soap or a slightly acidic, neutral or slightly alkaline detergent. Then rinse thoroughly with clean water and dry with chamois leather or a moist sponge. A subsequent anti-static treatment is recommended.
- Suitable cleaning solvents for MAKROCLEAR/ COLORADO at room temperature are water, white spirit, hexane, heptane, ethyl alcohol, butyl alcohol, isopropyl alcohol (also known as IPA or Isopropanol).
- Disinfection of the surface can be performed using > 60% isopropyl alcohol (IPA), ethanol, or any other antibacterial or antiviral cleaning agent suitable for PC, sprayed or applied on a soft cloth. If necessary, followed by a thorough wash with clean water and rinse as described above.
- Treatment with an anti-static agent keeps the sheet free from static charge and dust over prolonged periods. There are some commercially available products which act simultaneously as cleaning agent and anti-static agent, e.g. Burnus Kunststoff-Reiniger + Pfleger.

For more information contact info@arlaplast.se or check our website www.arlaplast.com

Arla Plast AB management system is certified according to AFS 2001:1, ISO 14001:2015 ISO 45001:2018 and ISO 9001:2015.